

Assembly manual UltraBead By-Pass

Make sure the O-rings are still in position.



Mount this threaded fittings in the 6-way valve



Now take the short part of the By-pass
and mount it on the outlet of the 6-way valve.



Mount the black part in the
white swivel



Then fix the union.
PLEASE NOTE!! Make sure the o-rings are present in the 3/3 union.

Now take the long part of the by-pass and
mount it on the inlet of the 6-way valve



Mount the black part in the
white swivel.



Then fix the union.
PLEASE NOTE!! Make sure the o-rings are present in the 3/3 union.
Now turn all swivels fixed.

Now mount the 6-way valve on the UltraBead

